



# Hydrometer Jar, 1000ml

A 1,000ml hydrometer jar is required for all soil hydrometer analysis. Hydrometers measure suspended solids in sedimentation cylinders over time periods of up to 24 hours. The jar is a heavy-wall clear glass cylinder with a steel base. A neoprene stopper is optional with the jar but helps prevent sample loss during agitation.

