



CBR Test Components: Surcharge Weights

Surcharge weights are used in the surcharge loads on the soil's surface during soaking and penetration. Weights are constructed with rust resistance.



- The 2-part Surcharge weight is 10 pounds and features two parts that are 5-7/8" OD and 2-1/8" ID.

- 5 pound surcharge weight has a 5-7/8" OD and 2-1/8" hold in the center.



- Slotted Surcharge weight is 10 pounds and is 8.5" in diameter.

- 5 pound slotted surcharge weight has a 5-7/8" OD and 2-1/8" slot.

