

REF.#	PART #	PART NAME	QUANT.
		M100-3 PARTS LIST	
		ALWAYS GIVE COMPLETE SERIAL NUMBER	
		WHEN ORDERING PARTS	
		Starting with S/N # M100-302143692	
1	102-A	Cover w/Hinges,Latch & Rivets	1
2	103	Latch Assy. w/ Rivets	1
3	104	Rivets for Hinges	12
4	105	Name Plate w/ rivets	1
5	111.1	Hammer Safety Arm 5/8" dia.	1
6	112	Pin for above	1
7	201	Drive Motor 60Hz	1
7	201.1	Drive Motor 50Hz	1
8	202	Gear Reducer	1
9	411	Capscrew (grade 2)	14
9.1	411.1	Capscrew	4
11	412.1	Lockwasher	18
12	412.2	Hex Nut	4
13	203	Brass Block	1
	203-A	Brass Block & Pin Assembly	1
14	204	Carrier Bolt	1
15	205	Lock-Nut	1
16	206	Carrier Link	1
17	207	Nylon Roller	1
18	203.1	Grease Fitting	2
19	208	Drive Chain	1
	208-A	Drive Chain w/Conn. & Carrier Link	1
20	209	Conecting Link	1
	209.1	Roller Link	1
21	210	Drive Sprocket	1
22	211	Key	1
23	212	Motor Key	1
30	2301.1	Carriage	1
	2301.1-A	Carriage Assy. w/all Parts	1
31	2302.1	Carriage Bushings	4
31.1	2302.2	Bushing Retaining Ring	4
33	304	Catch	1
	304-A	Includes: part 304,305 &306	
34	305	Steel Ball	1
35	306	Spring	1
36	308	Hold-Down Plate	2
37	309	Screw	4
40	401	Lower Angle Bracket	1
41	402	Upper Angle Bracket	1
42	402.1	Set Screw	2
45	403-A	Front Cage Bar Assy.w/all Parts	1
46	403.1	Pin	1
47	403.2	Lock-Pin	1
48	403.3	Retaining Pin	1
49	403.4	Spring	1
50	408	Cage Bar	2
51	409.1	Guide Bar	2
52	1410	Cam Bar	1
52	1410-A	Cambar Assy. w/lower & upper Cam	1
54	412	Flat Washer	2

REF.#	PART #	PART NAME	QUANT.
57	413	Upper Cam	1
58	414	Lower Cam	1
	414-A	includes: part 414,429 &430	
59	417	Hammer Surcharge weight	1
60	417.1	Screw,Hammer Weight	1
61	418	Top Cam Screw	1
62	419	Cage adjust Plate-Top	1
63	422	Lockwasher	12
63.1	422.1	Star Lockwasher	4
64	421	Hex Capscrew	8
65	420	Cage adjust Plate -Lower	1
66	423	Cambar Key	1
67	429	Pin, lower Cam	1
68	430	Lower Cam Spring	1
70	501A	Turntable & Shaft assembly, incl.515 Bearing	1
71	502	Turntable Base	1
72	503.2	Turntable Motor	1
73	504.2	Motor mounting Plate	1
74	505	Hex Capscrew	4
75	506	Washer	4
76	507	Drive Gear, 15 Teeth	1
77	508	Table Gear, 100 Teeth	1
78	509	Pin, Turntable	1
80	510.1	Screw, for cable clips	3
81	510.2	Nylon Cable Clip (small)	3
81.1	510.3	Cable clip (large)	1
83	513.1	Rollpin for 507	1
84	514	Rollpin for 508	1
85	515	Bearing	1
86.1	516.1	TT Motor shaft seal	3
87	522	Mold-Screw	2
90	601	Idler Bracket	1
91	602	Bearing	2
92	603	Snapping	1
93	604	Idler Sprocket	1
	604-A	Idler Sprocket w/ Bearings	1
94	605	Snapping	1
95	606	Hex Capscrew (grade 5)	4
96	606.1	Star Lockwasher	4
98	609	Setscrew, Chain adjustment	1
99	609.1	Hex Nut	8
100	701	Switch	1
100	701K	Switch Kit, incl.:1ea.701, 703,207,817. 2ea.704,705.	1
100.1	701.1	Door Switch w/Cord	1
101	702	Switch mounting Plate	1
102	703	Cover, Switch	2
103	702.1	Screw, TT motor & switch plate	5
104	702.2	Pivot Screw	1
105	704	Screw	2
105.1	705	Washer	4
105.2	705.1	Lockwasher	4
105.3	704.1	Switch mounting screw (door interlock)	2
	706	Switch cord	1
106	800.3-A	Complete Control	1
109	802	Rubber Mounts	4
	5655	Special Gear Oil	1